



Fireblock vertically every 10ft behind the wall.

Fireblock unfaced R-30 (typical on all joist bays).

Fireblock the ends of the soffit from the wall (typical).

Fireblock every 10ft along the soffit.

Fireblock between finished and unfinished area.

Fireblock in the float at the vertical fireblock position above.

FIREBLOCKING EXAMPLE

(Reference R302.11)