

Document Number:  
401300312

Date Received:  
06/05/2017

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: CHERYL LIGHT

Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461

Address: P O BOX 173779 Fax: (720) 929-7461

City: DENVER State: CO Zip: 80217- Email: CHERYL.LIGHT@ANADARKO.COM

**For "Intent" 24 hour notice required,** Name: Helgeland, Gary Tel: (970) 216-5749

**COGCC contact:** Email: gary.helgeland@state.co.us

API Number 05-123-25869-00

Well Name: TALLGRASS Well Number: 6-8

Location: QtrQtr: NESW Section: 8 Township: 1N Range: 68W Meridian: 6

County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_

Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.064436 Longitude: -105.029236

GPS Data:  
Date of Measurement: 05/20/2009 PDOP Reading: 5.0 GPS Instrument Operator's Name: CODY MATTSO

Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems

Other \_\_\_\_\_

Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_

Fish in Hole:  Yes  No If yes, explain details below

Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below

Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	8040	8056			
J SAND	8484	8502			
NIOBRARA	7682	7922			

Total: 3 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	928	580	928	0	VISU
1ST	7+7/8	4+1/2	11.6	8,575	795	8,575	3,376	CBL
S.C. 1.1				1,250	110	1,300	720	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 8434 with 2 sacks cmt on top. CIPB #2: Depth 7610 with 25 sacks cmt on top.  
CIBP #3: Depth 4454 with 2 sacks cmt on top. CIPB #4: Depth 80 with 25 sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 7610 ft. to 7210 ft. Plug Type: CASING Plug Tagged:   
Set 45 sks cmt from 1250 ft. to 878 ft. Plug Type: CASING Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
Set 25 sacks at surface  
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
of \_\_\_\_\_  
\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
Type of Cement and Additives Used: \_\_\_\_\_  
Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

\_\_\_\_\_

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: CHERYL LIGHT  
Title: SR REGULATORY ANALYST Date: 6/5/2017 Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: McCoy, Diane Date: 6/20/2017

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: 12/19/2017

COA Type	Description
	<p>1) Due to past bradenhead pressure; within 60 days prior to starting plugging operations, a bradenhead test shall be performed. The Form 17 shall be submitted within 10 days of the test. Prior to plugging, collect bradenhead and production gas samples for laboratory analysis. The gas analysis shall be for composition and stable carbon isotopes. The compositional analysis at a minimum shall include Hydrogen, Argon, Oxygen, Carbon Dioxide, Nitrogen, Methane, Ethene, Ethane, Propene, Propane, Isobutane, Butane, Isopentane, Pentane, Hexanes +, Specific Gravity and British Thermal Units (BTU). Stable carbon isotope analysis shall include delta DC1, delta 13C1, delta 13C2, delta 13C3, delta 13C4, delta 13NC4, delta 13C5 (if possible), delta 13NC5 (if possible), delta 13C6+ (if possible) and stable isotopes of CO2 if possible. If liquid is encountered in the bradenhead then collect samples, analysis of the liquid samples shall be conducted to provide an evaluation of the liquid source. Submit for the laboratory analysis of major anions (chloride, carbonate, bicarbonate, and sulfate), cations (sodium, potassium, calcium, and magnesium) total dissolved solids (TDS), BTEX, DRO, GRO and dissolved gasses (RSK 175). If there is a limited amount of water available then anions, cations and BTEX should be given first priority. If sufficient condensate is present to collect a sample then it should be submitted for whole oil by GC analysis or equivalent. The analysis should include the bio-markers Phytane and Pristane. Copies of all final laboratory analytical results shall be provided to the COGCC within three months of collecting the samples in an approved electronic data deliverable format.</p> <p>2) Provide 48 hour notice of plugging MIRU via electronic Form 42.</p> <p>3) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.</p> <p>4) After pumping plug from 1250-878', shut down and wait on cement at minimum 4 hours; verify gas migration has been eliminated. If evidence of gas migration or pressure remains contact COGCC Engineer for an update to plugging orders. Plug must be tagged at 878' or shallower. Leave at least 100' cement in the wellbore for each plug.</p>

### Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
401300312	WELL ABANDONMENT REPORT (INTENT)
401300318	PROPOSED PLUGGING PROCEDURE
401300319	WELLBORE DIAGRAM
401312861	FORM 6 INTENT SUBMITTED

Total Attach: 4 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Corrected casing setting depths and added stage cement. Added CIBP ato 80'. Moved CIBP #1 to be at least 50' above top J-sand perf.	06/20/2017
Public Room	Document verification complete 06/09/17	06/09/2017

Total: 2 comment(s)